

1. Place the kite so that the bridle is facing towards you and the tail is on the ground
2. Starting from the left, locate one of the metal rings on the outer edge of the kite, it has a small bungee attached to it (**illustration A**). Insert one of the spreaders through this ring. Push the spar through the middle metal ring (**illustration B**) and the outer ring on the opposite side (**illustration C**). Insert the bungees connected to the outer rings into the slots on the ends of the spreader.
3. On one of the main body spars, locate the two stoppers near the end of the spar. Take one of the small king post and connect one end between the two stoppers on the body spar (**illustration D**).
4. Connect the other end of the king post to the other body spar between the two stoppers.
5. Connect the king post center connector to the spreader where they cross (**illustration E**).
6. Repeat steps 3-5 for the right side.
7. Flip the kite over to the tail side.
8. Repeat steps 2-6 for this end.
9. Attach the flying line to the bridle.
10. Remove the end connectors from the rear king posts and slide the tail grommets onto the king posts. Replace end connectors. It is highly recommended that the end connectors be glued onto the king posts.

