


## Directions

1. Place the kite face down and insert the two loose spars into the pockets on the wingtips and then into the dihedral on the center spine. You may have to gently bend the cross spars to make them fit.
2. On the front side of the kite, remove the end cap on the short spar and replace the end cap.
3. Tie your flying line to the tow point (small loop) on the bridle.
4. Unroll the tails.



## Tips & Tricks!

Standing with your back to the wind, hold your kite up high pointing the nose skyward. When you feel the pressure of the wind against the kite, let go. As the kite rises, slowly release more line. When possible, have a friend help launch the kite. Tell your friend to stand downwind as you let out 25 feet of line. As the kite is released into the wind, tug on the line. The kite will begin to rise. Slowly release more line as the kite climbs higher into the sky.

If the kite starts to fall, take several quick steps back. This will create lift and the kite will rise again. If the kite goes into a nose dive, it is probably getting too much wind. Let out additional line or step towards the kite to release the pressure. Have fun!