




Directions

1. Slide the Leading Edge Spar down the Sleeve away from the nose to the bottom of the wing (trailing edge)
2. Locate the Spreader and insert into the pockets on the back side of the kite.
3. Locate the 8-4.5" spars you will use to attach the spinner to the wings. Insert each spar into the pockets located on the center of each wing. Make sure to insert the end with the endcap.
4. Locate the molded hub with pultruding spar. On the back side of the sail, insert the hub's spar through the hole in the sail. Then connect the 4-4.5" spars into the hub.
5. Remove cap from the hub spar and place spinning disk into it, replacing cap afterward.



Tips and Tricks!

1. Kites fly best in wide open spaces. Avoid flying in areas near buildings and trees.
2. To launch, stand with the wind to your back.
3. Hold the kite with the nose up in one hand while securely holding the winder in the other.
4. When you feel the pressure of the wind against the kite, let go. As the kite rises, slowly release the line.
5. A high altitude launch is an effective method of getting your kite off the ground in light winds. Have someone stand downwind as you let out as much line as possible (>100 feet). As the kite is released into the wind, tug on the line.