


Directions

1. Unroll the kite and place it face down. Insert the two longer spars through the casings on the top of the upper wings (leading edge) and then into the molded v-shaped connector on the upper center spine.
2. Slide the shorter spars into the holes located midway down the kite and through the casing on the top of the lower wing.
3. Insert the other end of the spreaders into the v-shaped connector on the middle part of the center spine.
4. Tie your flying line to the tow point (small loop) located on the bridle.



Tips and Tricks!

1. Kites fly best in wide open spaces. Avoid flying in areas near buildings and trees.
2. To launch, stand with the wind to your back.
3. Hold the kite with the nose up in one hand while securely holding the winder in the other.
4. When you feel the pressure of the wind against the kite, let go. As the kite rises, slowly release the line.
5. A high altitude launch is an effective method of getting your kite off the ground in light winds. Have someone stand downwind as you let out as much line as possible (>100 feet). As the kite is released into the wind, tug on the line.