




1. Unroll the kite and place face down on a flat surface. Check that the main spar is securely inserted into its pockets.




2. Find the long spar that runs around the outside of the head. Insert both ends into the pocket near the tail.



3. Insert the fin spar into the pocket on the opposite side of the main spar. Repeat for the other side.



4. Insert the tail spar into the pocket near the bottom of the main spar. Repeat for the other side.



### Tips & Tricks

1. Kites fly best in wide open spaces. Avoid flying in areas near buildings and trees.
2. To Launch, stand with the wind to your back.
3. Hold the kite with the nose up in one hand while securely holding the winder in the other.
4. When you feel the pressure of the wind against the kite, let go. As the kite rises, slowly release the line.
5. A high altitude launch is an effective method of getting your kite off the ground in light winds. Have someone stand downwind as you let out as much line as possible (>100 feet). As the kite is released into the wind, tug on the line.