




1. Unroll the kite and place face down on a flat surface. Check that the spars in red are securely inserted into their pockets.




2. Locate the spar extending from the top sleeve and insert it into the pocket. Repeat this for the bottom sleeve and spar.



3. Locate the spar attached to the main body spar by a rubber grommet. Insert each end into the pocket next to the top or bottom sleeve.



4. Insert the two loose spars into the tail pockets as shown.



### Tips & Tricks

1. Kites fly best in wide open spaces. Avoid flying in areas near buildings and trees.
2. To Launch, stand with the wind to your back.
3. Hold the kite with the nose up in one hand while securely holding the winder in the other.
4. When you feel the pressure of the wind against the kite, let go. As the kite rises, slowly release the line.
5. A high altitude launch is an effective method of getting your kite off the ground in light winds. Have someone stand downwind as you let out as much line as possible (>100 feet). As the kite is released into the wind, tug on the line.