



Step 1.

Rotate hull spreaders 90 degrees and push the two ends through the holes provided in the hull itself.

Step 2.

Connect the sails to the hull spreaders and put the end caps on the spar ends in the front and the back of the hull.





Step 3.

Clip-in the top horizontal sails by snapping them into the connector provided on the taller rod first. Next, put the loop over the hook above the connector, then snap and hook the opposite end to the shorter rod.

Step 4.

For the bottom horizontal sails, repeat step 3 for the connector on the lower end of the longest rod, then snap the opposite end to the shorter rod.



Step 5.

Attach the o-rings at the end of the line of the horizontal sails to the ends of the hull spreaders in the front and in the back.

Tips & Tricks!

1. Kites fly best in wide open spaces. Avoid flying in areas near buildings and trees.
2. To launch, stand with the wind to your back.
3. Hold the kite with the nose up in one hand while securely holding the winder in the other.
4. When you feel the pressure of the wind against the kite, let go. As the kite rises, slowly release the line.
5. A high altitude launch is an effective method of getting your kite off the ground in light winds. Have someone stand downwind as you let out as much line as possible (>100 feet). As the kite is released into the wind, tug on the line.