


Directions:

1. Unroll your kite and place it face down. Locate the 2 loose spars (1 short spar & 1 long).
2. Locate the ends of the 2 spars inserted into the tail fins. Insert these ends into the dihedral fitting located on the center spine. Make sure the dihedral is angling away from the sail.
3. Insert the long thin spar under the center spine and through the 2 unsewn seams on the casings located on each side of the rocket's nose. Take each end of the spar and insert them 5 inches into the opening.
When both spars are in the sleeve, gently slide each down to the bottom.
4. Place the shorter spar (cross spar) over the center spine and into the side pockets.
5. Turn your kite over and attached the flying line to the tow point (small loop) located on the bridle.



Tips & Tricks:

1. Kites fly best in wide open spaces. Avoid flying in areas near buildings and trees.
2. To Launch, stand with the wind to your back.
3. Hold the kite with the nose up in one hand while securely holding the winder in the other.
4. When you feel the pressure of the wind against the kite, let go. As the kite rises, slowly release the line.
5. A high altitude launch is an effective method of getting your kite off the ground in light winds. Have someone stand downwind as you let out as much line as possible (>100 feet). As the kite is released into the wind, tug on the line.