


Directions

1. Unroll the kite and place it face down.
2. Insert the long thin spar under the center spine and through the unsewn seam on the casing located on each side of the nose. (see illustration)
3. Place the shorter spar (cross spar) over the spine and into the side pockets.
4. Tie your flying line to the tow point (small loop) on the bridle.



Tips & Tricks!

1. Kites fly best in wide open spaces. Avoid flying in areas near buildings and trees.
2. To launch, stand with the wind to your back.
3. Hold the kite with the nose up in one hand while securely holding the winder in the other.
4. When you feel the pressure of the wind against the kite, let go. As the kite rises, slowly release the line.
5. A high altitude launch is an effective method of getting your kite off the ground in light winds. Have someone stand downwind as you let out as much line as possible (>100 feet). As the kite is released into the wind, tug on the line.