



Directions

1. Make sure the four arm & leg spars are slid to the bottom of each sleeve.
2. Begin assembly by inserting the end of one leg spar into the fitting of the opposite side arm spar. Repeat.
3. Insert the end of one arm spar into the fitting located on the opposite leg spar. Repeat.
4. Insert the short spar into the head.
5. Attach your flying line to the Tow Point located on the bridle.

Tips & Tricks

1. Kites fly best in wide open spaces. Avoid flying in areas near buildings and trees.
2. To launch, stand with wind to your back.
3. Hold the kite with the nose up in one hand while securely holding the winder in the other.
4. When you feel the pressure of the wind against the kite, let go. As the kite rises, slowly release the line.
5. A high altitude launch is an effective method of getting your kite off the ground in light winds. Have someone stand downwind as you let out as much line as possible (>100 feet). As the kite is released into the wind, tug on the line.