


Directions

1. Unfold kite and place it face down.
2. Insert the shorter spar into the reinforced pockets on the edges of the wing.
3. Make sure that the pre-inserted spars are moved down from the nose to the tips of the wings.
4. Find the unsewn seam at the top of the tail (see illustration) and insert the long thin spar gently down into the seam.
5. Tie your line to the tow point (small loop) on the bridle.



Tips and Tricks!

1. Kites fly best in wide open spaces. Avoid flying in areas near buildings and trees.
2. To launch, stand with the wind to your back.
3. Hold the kite with the nose up in one hand while securely holding the winder in the other.
4. When you feel the pressure of the wind against the kite, let go. As the kite rises, slowly release the line.
5. A high altitude launch is an effective method of getting your kite off the ground in light winds. Have someone stand downwind as you let out as much line as possible (>100 feet). As the kite is released into the wind, tug on the line.