



Directions


1. Make sure the (2) "cross spars" are slid thru the center tab, then to the ends of each "sleeve".
2. Insert the opposite end of the "cross spars" into the other pockets provided half way down the kite.



3. Then insert the "bottom spar" into the two pockets provided at the bottom portion of the kite.



4. Attach your flying line to the "Tow Point" located on the "bridle".



Tips & Tricks

1. Kites fly best in wide open spaces. Avoid flying in areas near buildings and trees.
2. To launch, stand with wind to your back.
3. Hold the kite with the nose up in one hand while securely holding the winder in the other.
4. When you feel the pressure of the wind against the kite, let go. As the kite rises, slowly release the line.
5. A high altitude launch is an effective method of getting your kite off the ground in light winds. Have someone stand downwind as you let out as much line as possible (>100 feet). As the kite is released into the wind, tug on the line.